



Remove the small dongle on the back of PV44 (keep it in a safe place) and connect the expansion via the ribbon cable supplied.

When only the original "MOD" input ● is used, it will modulate the A/B/C/D rows as usual.

This original modulation input becomes modulation Group I when a jack is plugged to the "GP II" input ●.

The switch lets you chose the destinations for both groups, which minimizes the need of multiples.

The individual inputs ● have the priority on the groups and allow modulation per row, or various combinations with the modulation groups.

XO DEVICES
&
ENGINEERING SERVICES

WWW.XODES.NET

MADE IN FRANCE